

# PANEL WIDTH CHART (in inches)

Dimensions shown are out-to-out of bearing bars (Add 1/4" for extended cross rods)

No. of Bars	1/4 Bar	No. of Bars	1/4 Bar	No. of Bars	1/4 Bar	No. of Bars	1/4 Bar
2	15/16	15	9-7/8	28	18-13/16	41	27-3/4
3	1-5/8	16	10-9/16	29	19-1/2	42	28-7/16
4	2-5/16	17	11-1/4	30	20-3/16	43	29-1/8
5	3	18	11-15/16	31	20-7/8	44	29-13/16
6	3-11/16	19	12-5/8	32	21-9/16	45	30-1/2
7	4-3/8	20	13-5/16	33	22-1/4	46	31-3/16
8	5-1/16	21	14	34	22-15/16	47	31-7/8
9	5-3/4	22	14-11/16	35	23-5/8	48	32-9/16
10	6-7/16	23	15-3/8	36	24-5/16	49	33-1/4
11	7-1/8	24	16-1/16	37	25	50	33-15/16
12	7-13/16	25	16-3/4	38	25-11/16	51	34-5/8
13	8-1/2	26	17-7/16	39	26-3/8	52	35-5/16
14	9-3/16	27	18-1/8	40	27-1/16	53	36