

PANEL WIDTH CHART

(in inches)

Dimensions shown are
out-to-out of bearing bars

No. of Bars	1/4 Bar	No. of Bars	1/4 Bar
2	1	26	19
3	1-3/4	27	19-3/4
4	2-1/2	28	20-1/2
5	3-3/4	29	21-1/4
6	4	30	22
7	4-3/4	31	22-3/4
8	5-1/2	32	23-1/2
9	6-1/4	33	24-1/4
10	7	34	25
11	7-3/4	35	25-3/4
12	8-1/2	36	26-1/2
13	9-1/4	37	27-1/4
14	10	38	28
15	10-3/4	39	28-3/4
16	11-1/2	40	29-1/2
17	12-1/4	41	30-1/4
18	13	42	31
19	13-3/4	43	31-3/4
20	14-1/2	44	32-1/2
21	15-1/4	45	33-1/4
22	16	46	34
23	16-3/4	47	34-3/4
24	17-1/2	48	35-1/2
25	18-1/4	49	36-1/4