

PANEL WIDTH CHART (in inches) Dimensions shown are out-to-out of bearing bars (Add 1/4" for extended cross rods)					
No. of Bars	1/8 Bar	3/16 Bar	No. of Bars	1/8 Bar	3/16 Bar
2	5/8	11/16	38	18-5/8	18-11/16
3	1-1/8	1-3/16	39	19-1/8	19-3/16
4	1-5/8	1-11/16	40	19-5/8	19-11/16
5	2-1/8	2-3/16	41	20-1/8	20-3/16
6	2-5/8	2-11/16	42	20-5/8	20-11/16
7	3-1/8	3-3/16	43	21-1/8	21-3/16
8	3-5/8	3-11/16	44	21-5/8	21-11/16
9	4-1/8	4-3/16	45	22-1/8	22-3/16
10	4-5/8	4-11/16	46	22-5/8	22-11/16
11	5-1/8	5-3/16	47	23-1/8	23-3/16
12	5-5/8	5-11/16	48	23-5/8	23-11/16
13	6-1/8	6-3/16	49	24-1/8	24-3/16
14	6-5/8	6-11/16	50	24-5/8	24-11/16
15	7-1/8	7-3/16	51	25-1/8	25-3/16
16	7-5/8	7-11/16	52	25-5/8	25-11/16
17	8-1/8	8-3/16	53	26-1/8	26-3/16
18	8-5/8	8-11/16	54	26-5/8	26-11/16
19	9-1/8	9-3/16	55	27-1/8	27-3/16
20	9-5/8	9-11/16	56	27-5/8	27-11/16
21	10-1/8	10-3/16	57	28-1/8	28-3/16
22	10-5/8	10-11/16	58	28-5/8	28-11/16
23	11-1/8	11-3/16	59	29-1/8	29-3/16
24	11-5/8	11-11/16	60	29-5/8	29-11/16
25	12-1/8	12-3/16	61	30-1/8	30-3/16
26	12-5/8	12-11/16	62	30-5/8	30-11/16
27	13-1/8	13-3/16	63	31-1/8	31-3/16
28	13-5/8	13-11/16	64	31-5/8	31-11/16
29	14-1/8	14-3/16	65	32-1/8	32-3/16
30	14-5/8	14-11/16	66	32-5/8	32-11/16
31	15-1/8	15-3/16	67	33-1/8	33-3/16
32	15-5/8	15-11/16	68	33-5/8	33-11/16
33	16-1/8	16-3/16	69	34-1/8	34-3/16
34	16-5/8	16-11/16	70	34-5/8	34-11/16
35	17-1/8	17-3/16	71	35-1/8	35-3/16
36	17-5/8	17-11/16	72	35-5/8	35-11/16
37	18-1/8	18-3/16	73	36-1/8	36-3/16