

# **PANEL WIDTH CHART** (in inches)

Dimensions shown are out-to-out of bearing bars (Add 1/4" for extended cross rods)

<b>No. of Bars</b>	<b>3/16 Bar</b>	<b>No. of Bars</b>	<b>3/16 Bar</b>
2	7/8	28	18-3/4
3	1-9/16	29	19-7/16
4	2-1/4	30	20-1/8
5	2-15/16	31	20-13/16
6	3-5/8	32	21-1/2
7	4-5/16	33	22-3/16
8	5	34	22-7/8
9	5-11/16	35	23-9/16
10	6-3/8	36	24-1/4
11	7-1/16	37	24-15/16
12	7-3/4	38	25-5/8
13	8-7/16	39	26-5/16
14	9-1/8	40	27
15	9-13/16	41	27-11/16
16	10-1/2	42	28-3/8
17	11-3/16	43	29-1/16
18	11-7/8	44	29-3/4
19	12-9/16	45	30-7/16
20	13-1/4	46	31-1/8
21	13-15/16	47	31-13/16
22	14-5/8	48	32-1/2
23	15-5/16	49	33-3/16
24	16	50	33-7/8
25	16-11/16	51	34-9/16
26	17-3/8	52	35-1/4
27	18-1/16	53	35-15/16