

# PANEL WIDTH CHART

Dimensions shown  
are out-to-out of  
bearing bars (Add  
1/4" for extended  
cross rods)

No. of Bars	1/4 Bar
2	1-7/16
3	2-5/8
4	3-13/16
5	5
6	6-3/16
7	7-3/8
8	8-9/16
9	9-3/4
10	10-15/16
11	12-1/8
12	13-5/16
13	14-1/2
14	15-11/16
15	16-7/8
16	18-1/16
17	19-1/4
18	20-7/16
19	21-5/8
20	22-13/16
21	24
22	25-3/16
23	26-3/8
24	27-9/16
25	28-3/4
26	29-15/16
27	31-1/8
28	32-5/16
29	33-1/2
30	34-11/16
31	35-7/8