

# PANEL WIDTH CHART

(in inches)

Dimensions shown are out-to-out of bearing bars  
(Add 1/4" for extended cross rods)

No. of Bars	1/8 Bar	3/16 Bar	No. of Bars	1/8 Bar	3/16 Bar
2	9/16	5/8	43	18-1/2	18-9/16
3	1	1-1/16	44	18-15/16	19
4	1-7/16	1-1/2	45	19-3/8	19-7/16
5	1-7/8	1-15/16	46	19-13/16	19-7/8
6	2-5/16	2-3/8	47	20-1/4	20-5/16
7	2-3/4	2-13/16	48	20-11/16	20-3/4
8	3-3/16	3-1/4	49	21-1/8	21-3/16
9	3-5/8	3-11/16	50	21-9/16	21-5/8
10	4-1/16	4-1/8	51	22	22-1/16
11	4-1/2	4-9/16	52	22-7/16	22-1/2
12	4-15/16	5	53	22-7/8	22-15/16
13	5-3/8	5-7/16	54	23-5/16	23-3/8
14	5-13/16	5-7/8	55	23-3/4	23-13/16
15	6-1/4	6-5/16	56	24-3/16	24-1/4
16	6-11/16	6-3/4	57	24-5/8	24-11/16
17	7-1/8	7-3/16	58	25-1/16	25-1/8
18	7-9/16	7-5/8	59	25-1/2	25-9/16
19	8	8-1/16	60	25-15/16	26
20	8-7/16	8-1/2	61	26-3/8	26-7/16
21	8-7/8	8-15/16	62	26-13/16	26-7/8
22	9-5/16	9-3/8	63	27-1/4	27-5/16
23	9-3/4	9-13/16	64	27-11/16	27-3/4
24	10-3/16	10-1/4	65	28-1/8	28-3/16
25	10-5/8	10-11/16	66	28-9/16	28-5/8
26	11-1/16	11-1/8	67	29	29-1/16
27	11-1/2	11-9/16	68	29-7/16	29-1/2
28	11-15/16	12	69	29-7/8	29-15/16
29	12-3/8	12-7/16	70	30-5/16	30-3/8
30	12-13/16	12-7/8	71	30-3/4	30-13/16
31	13-1/4	13-5/16	72	31-3/16	31-1/4
32	13-11/16	13-3/4	73	31-5/8	31-11/16
33	14-1/8	14-3/16	74	32-1/16	32-1/8
34	14-9/16	14-5/8	75	32-1/2	32-9/16
35	15	15-1/16	76	32-15/16	33
36	15-7/16	15-1/2	77	33-3/8	33-7/16
37	15-7/8	15-15/16	78	33-13/16	33-7/8
38	16-5/16	16-3/8	79	34-1/4	34-5/16
39	16-3/4	16-13/16	80	34-11/16	34-3/4
40	17-3/16	17-1/4	81	35-1/8	35-3/16
41	17-5/8	17-11/16	82	35-9/16	35-5/8
42	18-1/16	18-1/8	83	36	36-1/16