

PANEL WIDTH CHART

(in inches)

Dimensions shown are out-to-out of bearing bars

No. of Bars	1/4 Bar	No. of Bars	1/4 Bar	No. of Bars	1/4 Bar
2	3/4	26	12-3/4	50	24-3/4
3	1-1/4	27	13-1/4	51	25-1/4
4	1-3/4	28	13-3/4	52	25-3/4
5	2-1/4	29	14-1/4	53	26-1/4
6	2-3/4	30	14-3/4	54	26-3/4
7	3-1/4	31	15-1/4	55	27-1/4
8	3-3/4	32	15-3/4	56	27-3/4
9	4-1/4	33	16-1/4	57	28-1/4
10	4-3/4	34	16-3/4	58	28-3/4
11	5-1/4	35	17-1/4	59	29-1/4
12	5-3/4	36	17-3/4	60	29-3/4
13	6-1/4	37	18-1/4	61	30-1/4
14	6-3/4	38	18-3/4	62	30-3/4
15	7-1/4	39	19-1/4	63	31-1/4
16	7-3/4	40	19-3/4	64	31-3/4
17	8-1/4	41	20-1/4	65	32-1/4
18	8-3/4	42	20-3/4	66	32-3/4
19	9-1/4	43	21-1/4	67	33-1/4
20	9-3/4	44	21-3/4	68	33-3/4
21	10-1/4	45	22-1/4	69	34-1/4
22	10-3/4	46	22-3/4	70	34-3/4
23	11-1/4	47	23-1/4	71	35-1/4
24	11-3/4	48	23-3/4	72	35-3/4
25	12-1/4	49	24-1/4		